


GENERAL OVERVIEW

CAUTION – ELECTRICAL POWERED PRODUCT!

OPERATION OF BLOWER UNIT BY ADULTS ONLY. WHEN USING
ANY ELECTRICAL PRODUCT, PRECAUTION SHOULD BE TAKEN TO
PREVENT ELECTRIC SHOCK.



CONTENTS

- (1) Inflatable Bouncer Unit
- (1) Carrying Bag
- (1) Blower

- (4 to 6) Bouncer Stakes
- (4) Blower Stakes
- Repair Patches & Thread

GROUNDING INSTRUCTIONS

This product must be grounded—the grounding pin provides an escape route for the electrical current. If electrical short circuit occurs, grounding reduces the risk of shock. This cord attached blower is equipped with a grounding wire and grounding pin. When using blower, plug into an outlet that is properly grounded, in accordance with all local codes.



WARNING: Incorrect installation of the grounding plug may result in electrical shock. Check with a qualified electrician if the grounding instructions are not completely understood or if you have any doubts about grounding set-up. Do not modify the plug provided (have an electrician replace outlet, with proper outlet). Blower is compatible for use with a nominal 120-V circuit. **Do not use an adapter with this blower's plug.**



WARNING: Failure to follow these instructions could result in injury or death.

!\ELECTRICAL BLOWER (SAFETY WARNING!)

DANGER: To prevent electric shock, do not immerse in (wipe clean with dry cloth. Failure to follow these instructions could result in injury or death.

CAUTION: The blower operates at high volume, which moves the air very quickly. Place the blower in an open area—free from dirt and leaves. Keep the blower away from water and walkways. Keep children away from blower. The blower that is provided should be the only blower used for inflation.

INSTRUCTIONS FOR BLOWER INSTALLATION

Set up inflatable unit and blower as close to power source as possible. Periodically examine the blower for unsafe conditions, such as;

- damaged cord
- damaged plug
- damaged housing or other parts
 DO NOT use a damaged blower (repair or
 replace). Never leave blower outside in rainy or
 extreme weather conditions. During operation
 do not place blower cord across traffic path.
 Keep cord away from water or damp ground.
 The blower should be place on a level/stable
 surface and anchored, per instructions. NOTE:
 the power cord is equipped with a Ground Fault
 Current Interrupter (GFCI) plug.
- Make sure the blower switch is in the 'OFF' position—plug blower into a proper grounded, 110-120V GFCI outlet.
- 2.) If you notice the GFCI has been tripped, press the 'reset' button to restore power.
- 3.) Connect blower to unit.
- 4.) Set the power switch of the blower to 'ON' to inflate unit.
- NOTE: Inflatables require constant air flow during operation.
- 5.) Adults should be handling blower ONLY.

WARNING:

- ADULT SET-UP and SUPERVISION REQUIRED.
- Use only with a GFCI receptacle.
- This blower is for residential use ONLY—it is not to be used for commercial applications.
- Never insert foreign objects in the grill covering, at any time.
- If the cord becomes damaged, do not operate the blower—also if the blower is damaged in any manner, do not operate.
- Do not operate when flammable/explosive fumes are detected.
- Never connect any solid-state speed control device to this blower (fire hazard).
- WARNING- electric hazard- don not use extension cords with this blower.
- Always unplug the blower before any cleaning or servicing.
- Blower intended for outdoor use only.

INSTRUCTIONS FOR BLOWER CLEANING AND STORAGE

DO NOT CLEAN WITH WATER. Do not immerse the blower in water. Unplug the blower before any cleaning. Clean with a dry or damp cloth. This blower does not require any lubrication—and has no parts that need servicing. Do not attempt to service the blower yourself. Store the blower indoors when not in use—the space should be dry also. Store the blower upright on a stable surface. Do not leave cord unwound, loop and coil the cord to prevent damage.

SET UP (SAFETY WARNING!) Users must for instructions.

Users must follow these instructions.

- ADULT SET UP REQUIRED. This unit should be inflated and deflated by adults only.
- Do not set up on hard surfaces, such as; concrete, asphalt, hard dirt or wood—falls to hard surfaces can result in serious injury.
- This unit is heavy, use caution when lifting.
- This inflatable is intended for residential use
 —not for public, commercial or rental use.
- Do not drag unit across concrete pavement or other rough surfaces.
- WARNING: Keep inflatable away from fire, or any ignition sources.
- Do not set up in windy conditions or extreme weather—product may lift off the ground.
- Set up in outdoor locations only. Place on level ground, covered with grass—for safety and proper use of stakes.
- Stakes should be driven in vertically and place low to the ground, to prevent tripping.

- Clearance zone: The unit should be at least 6 ft. away from any other objects. (see set up illustration). Pay careful attention to overhead branches, laundry lines electrical lines and bodies of water.
- The blower cord should not pass under the inflatable unit.
- The blower, that powers the unit, is to be used by an adult only.
- Keep children away from power cord and blower.
- ATTENTION: The blower should remain 'ON', running continuously, during the use of inflatable unit. Any airflow through the seams is normal—do not attempt to cover seams.

SAFETY WARNINGS!

Failure to follow these warnings could result in serious injury or death.



NO SHOES



NO SHARP OBJECTS, OR TOYS



NO GLASSES



NO JEWELRY



NO FOOD OR DRINKS



NO UNEVENLY MATCHED PLAYERS



NO ROUGH PLAY



NO TUMBLING OR FLIPPING

!\SAFETY WARNINGS! (Continued)



NO PERSONS W/ MEDICAL CONDITIONS



KEEP HANDS & FEET AWAY FROM NETTING



MAXIMUM NUMBER OF PLAYERS 4



MINIMUM HEIGHT 3 ft.



MAXIMUM HEIGHT 5 ft.



MAXIMUM WEIGHT PER PLAYER 75 lbs



TOTAL MAXIMUM WEIGHT 300 lbs



DO NOT USE IN HIGH WIND CONDITIONS-OVER 15 MPH

- ADULT supervision is REQUIRED at ALL times—follow all operating instruction.
- Do not place inflatable near fire or heat of any kind.
- Suitable for children ages 3-10 years old.
- Be aware of the inherent risk of injury.
- If unit begins to deflate EXIT immediately.
- Unauthorized modifications are not allowed.
- A 'Clearance Zone' of 6 ft. around the unit should be adhered to, at a minimum.
- PLACE unit on dry, even, soft ground only free from debris
- KEEP children away from blower, during operation
- DO NOT allow children to play on unit/game until it is fully inflated
- CLOTHING should not be loose—no scarves, hoods or drawstrings
- NO PETS allowed near or on unit
- DO NOT Inflate or use this inflatable without first SECURING to ground
- DRY UNITS (without hose) should be dry before play begins
- JUMP ROPES, clotheslines, pet leashes or any item shouldn't be attached to unit (strangulation hazard)
- GROUND USE, this unit shouldn't be placed in a pool or water

- Children should not jump onto or off of the unit
- SHOCK HAZARD! Do not use this equipment on damp surfaces or during inclement or extreme weather
- DO NOT drag unit across rough surfaces
- STORAGE: when not in use, store in a shaded, dry area
- AVOID injury: strictly observe maximum occupancy
- CHECK for air loss and proper staking before and during use
- PERIODICALLY examine for unsafe conditions: rips, frayed cords etc.
- BEFORE deflation, remove all children always store indoors

THIS UNIT REQUIRES A CONSTANT SOURCE OF 110V-20amp power per blower system (air leakage is normal during operation)

\sum WATER SAFETY WARNINGS! (for units with water feature)



ADULT SUPERVISION REQUIRED AT ALL TIMES


- DANGER: No diving or jumping— serious injury or death risk!
- WARNING: Water in pool area is shallow!
- No running, jumping or horseplay in pool area.
- No back flips or somersaults.
- Do not go down slide backwards. Use proper sliding form:
- Slide feet first
- Arms folded
- Feet together


- CAUTION: Children can drown in small amounts of water.
- Pool should be emptied when not in use.
- Always slide down the slide feet first, to avoid injury.
- One child should be using slide, only.
- One child, at a time, on the climb, only.
- MONITOR POOL: Splash down area must be clear before a child slides down slide.
- Do not slide down or jump off climbing steps.
- WARNING: Slippery surfaces—potential tripping hazard.

PROPER SLIDING:


- Climb up the climbing steps to the top.
- Sit on the top of slide with feet point down the slide.
- Scoot forward (using hands) and slide down the slide, on your back.
- Arms folded and feet together, once in in a full sliding motion.
- DO NOT slide down on your stomach or head first.
- Do not leave full of water or inflated overnight.
- Keep pool area clean (use chemical-free sprays)
- Instruct children never to drink pool water.


CLEARANCE ZONE (around the entire inflatable unit)








SET UP


















SET UP (continued)













SET UP (inflation and staking)













DEFLATION













REFOLDING and STORAGE













INFLATABLE MAINTENANCE

- First a foremost, dry out your inflatable by running air through it, with the blower.
- Remove excess water (for water units) and sponge dry.
- Keep your inflatable clean by wiping with a dry cloth, or damp sponge. Any cleaning agents should be Non-Toxic and natural.
- Continue to dry the inflatable after cleaning.
- NEVER roll up or store the inflatable if wet, in any amount.
- Patch and thread are provide to repair large tears—round off corners, then sew.
- You can obtain self-adhesive 'Patch-All' patches from PogoBounceHouse.com.

BLOWER MAINTENANCE

- Unplug blower after every use.
- The blower should be examined, periodically, for damaged housing, a damaged cord or other damaged parts. A well functioning blower is critical for the safe use of your inflatable.
- Do not attempt to service the blower. The blower does not require any lubrication.
- Before use, check the intake area and blower chute to make sure it is free of debris.
- Store the blower indoors, in a dry location— stand it upright.

Limited Warranty

POGO Bounce House will warrant to the original purchaser that this product is free of defects in the fabric or workmanship for a period of (90) days from the date of purchase. The same holds true for the blower, that this product is free of defects or workmanship for a period of (90) days from the date of purchase (a dated sales invoice/receipt is required for proof of purchase). This warranty is not valid if the product hasn't been assembled or maintained correctly, per the instructions herein. This warranty does not cover normal wear issues like; fading, scratches, accidental punctures, harsh handling damage—or any other damage that differs from an original defect in material or production workmanship.

POGO Bounce House has the sole discretion to remedy claims in one of two ways—judgment to replace a defective item or refund of the purchase price of the unit.

For warranty information please visit PogoBounceHouse.com or call (716) 566-5806. This warranty provides you with specific legal rights—you may have other rights, as a consumer. Additional rights may be granted, which varies from state to state.